

Motorola XTS 5000 MVP25 Generic

www.miamivalleyp25.group

FLASHcode: 560081-001B06-5

Firmware: 5.07.15

Radio Configuration → Radio Wide → General:

- User Information → SoftID/Username:
 - ARS User Login Enable
 - <ENTER FCC CALL>
- Radio ID Alias Enabled
- Radio ID Alias <ENTER FCC CALL>

Conventional → MDC → MDC Call List

NOTE: All ID's are aliased in MDC Call lists above Call List 1.

Use Call List 1 to maintain selectable ID's you wish to page or call from the radio.

- MDC Call List 1
 - Enter all MDC ID's you want listed in the Page and Call list.

Conventional → MDC → MDC System

- Enter MDC ID as registered with MVP25

Radio Configuration → Conventional __ASTRO Systems → ASTRO Call List

NOTE: All ID's are aliased in ASTRO Call lists above Call List 1.

Use ASTRO Call List 1 to maintain selectable ID's you wish to page or call from the radio.

- ASTRO Call List 1
 - Enter all ASTRO ID's you want listed in the Page and Call list.

Radio Configuration → Conventional __ASTRO Systems → ASTRO System

- Enter Radio ID as registered with MVP25

Tools → Cloning → Clone Radio:

- Read Serial Number
- View MDC IDs
 - Adjust as registered with MVP25
- View ASTRO IDs
 - Adjust as registered with MVP25
- Program Radio